

Rollenschneider
Rotary Trimmer
Coupeuse
Rolsnijder
Taglierina a lama rotante
Cizalla de rodillo
Роликовый резак

IDEAL 0055

IDEAL 0075





IDEAL 0105



DE Betriebsanleitung
EN Operating Instructions
FR Mode d'emploi
NL Gebruiksaanwijzing
IT Manuale d'istruzione
ES Instrucciones de uso
RU Инсталляция




Keine Bedienung durch Kinder!
Children must not operate the machine!
Pas d'utilisation par un enfant!
Bediening niet door kinderen!
Non lasciare utilizzare il tagliacarte a bambini!
No dejar que la utilicen los niños!
Не допускайте детей к пользованию аппаратом!



IDEAL 0105 U

- DE Aufbauanleitung • EN Installation • FR Montage • NL Installatie •
- IT Installazione • ES Instalación • RU Инсталляция •



Krug & Priester GmbH & Co. KG
 Simon-Schweitzer-Str. 34
 D-72336 Balingen (Germany)

9700253 IDEAL 02-2014 02.04.2019 zm