

Betriebsanleitung

Operating Instructions

Mode d'emploi

Gebruiksaanwijzing

Manuale d'istruzione

Instrucciones de uso

Manual de instruções

Инструкция по эксплуатации



Keine Bedienung durch Kinder!

Children must not operate the machine!

Pas d'utilisation par un enfant!




Bediening niet door kinderen!

Non lasciare utilizzare il tagliacarte a bambini!

No dejar que la utilicen los niños!

Crianças não devem operar com a máquina!

Не допускайте детей к пользованию аппаратом!



Rollenschneider

Rotary Trimmer

Coupeuse

Rolsnijder

Taglierina a lama rotante

Cizalla de rodillo

Cisalhas

Роликовый резак

IDEAL 0135

IDEAL 0155



Optional - Option - En option - Опция

Betriebsanleitung

Operating Instructions

Mode d'emploi

Gebruiksaanwijzing

Manuale d'istruzione

Instrucciones de uso

Manual de instruções

Инструкция по эксплуатации



Keine Bedienung durch Kinder!

Children must not operate the machine!

Pas d'utilisation par un enfant!

Bediening niet door kinderen!

Non lasciare utilizzare il tagliacarte a bambini!

No dejar que la utilicen los niños!

Crianças não devem operar com a máquina!

Не допускайте детей к пользованию аппаратом!

